

Instruction For Water Blower A22-2300/TA22-2300/VA22-2300

A22-2300/TA22-2300/VA22-2300 is second-generation double motors blaster with wind speed adjustable. With improved structure design it has feature of high-power ($\leq 2800W$), wind speed adjustable, heating function and unique nozzle connector, etc. It has lower noise and stronger wind speed compare with first generation. It is a must for pets' hair drying and grooming.

1. Out-let
2. Air put-let
3. The flexible tube
4. Power switch
5. The air intake net cover
6. Heating switch
7. Wind speed switch
8. The fixing screw



Operation of the Water Blower:

1. Insert the flexible tube(3)(without the heat insulation sleeve) into the water blower's air out-let, and then anti-clockwise twist to make it tight.
2. Choose a suitable nozzle(1), and then anti-clockwise twist on the flexible tube to make it tight. According to your need, choose the suitable hose coupler(as showed in the picture).
3. According to the assigned voltage, choose the proper one, (230V or 110V), or the blower might be damaged by the wrong voltage.
4. Clean the air intake net leaf regularly. Remove the fixing screw and air intake net cover, and then you can do the cleaning and change, which can prevent the air intake from being blocked and thus can protect the motor.
5. If the motor does not work, please check whether the power supply has been connected. If the connection and contact are good but the product still can not work properly, send it to some professional men for fix. Please do not disassemble the product arbitrarily.

Tips: Do not take it into the bathroom.

